


Kids Footwear Size Conversion Charts

kids



Infants/Toddler

USA	UK	Europe	CM*
2C	1.5	17	8
2.5C	2	17.5	8.5
3C	2.5	18	9
3.5C	3	18.5	9.5
4C	3.5	19	10
4.5C	4	19.5	10.5
5C	4.5	20	11
5.5C	5	21.5	11.5
6C	5.5	22	12
6.5C	6	22.5	12.5
7C	6.5	23.5	13
7.5C	7	24	13.5
8C	7.5	25	14
8.5C	8	25.5	14.5
9C	8.5	26	15
9.5C	9	26.5	15.5

Preschool

USA	UK	Europe	CM*
10C	9.5	27	16
10.5C	10	27.5	16.5
11C	10.5	28	17
11.5C	11	28.5	17.5
12C	11.5	29	18
12.5C	12	29.5	18.5
13C	12.5	31	19
13.5C	13	31.5	19.5

Youth (Grade School)

USA	UK	Europe	CM*
1Y	13.5	32	20
1.5Y	1	33	20.5
2Y	1.5	33.5	21
2.5Y	2	34	21.5
3Y	2.5	35	22
3.5Y	3	35.5	22.5
4Y	3.5	36	23
4.5Y	4	36.5	23.5
5Y	4.5	37.5	23.5
5.5Y	5	38	24
6Y	5.5	38.5	24
6.5Y	6	39	24.5
7Y	6	40	25

These break across two size ranges:

Group	Size range
Children	1-13.5c
Youth	1-7y

Group	Age	Footwear size
Infant	0-9m	Baby or Infant 1-4c
Toddler	0-4y	Toddler 2c-10c
Preschool	4-7	10c-3y
Grade school	7-12	3.5y-7y

Age	Average Shoe Size
2-3 months	0C-2C
6 months	3C-4C
1 year	5C-6C
18 months	6C-7C
2-21/2 years	7C-8C
3-4 years	9C-10C
5-6 years	11C-12C
7-8 years	12C-13C
9-10 years	1Y-2Y
11-13 years	3Y-7Y